

INSTALLATION INSTRUCTIONS



No. 940207




CUSTOM MOLDED REAR MUD GUARDS FOR GMC SIERRA

Tools Needed

- Phillips head screwdriver
- Drill with 1/8" drill bit

Included in Box

- Rear Mud Guards (for driver & passenger side)
- #10 Screws (x6)
- #10 Washers (x6)



Repeat Steps 1-3 for Driver & Passenger Side

STEP 1. Use the mud guard as a template to mark holes at location A, B, and C.

STEP 2. Drill a 1/8" hole into fender at locations A, B, and C.

STEP 3. Attach mud guard to fender with #10 Screws and Washers at newly-drilled hole locations A, B and C.

INSTALLATION INSTRUCTIONS



No. 940202




CUSTOM MOLDED FRONT MUD GUARDS FOR GMC SIERRA

Tools Needed

- T-15 Torx Driver
- Phillips head screwdriver
- Drill with 1/8" drill bit

Included in Box

- Front Mud Guards (for driver & passenger side)
- Film to protect vehicle
- #10 Screws (x2)
- #10 Washers (x2)



Repeat Steps 1-3 for Driver & Passenger Side

STEP 1. Remove existing fasteners.

- a. Remove your existing fasteners from locations A and B. These will be reused again in Step 3.
- b. Do NOT remove the factory fastener located at location C.

STEP 2. Apply film to protect vehicle.

- a. Using a clean cloth or wet alcohol pad, clean the area on the fender where the film (to protect vehicle) will be placed.
- b. Use soapy water to wet film, fender, and fingers for a wet film installation. Apply film in location shown in diagram, with adhesive side of film towards the vehicle. Apply pressure and smooth out film with a squeegee or sponge and allow to dry.

STEP 3. Install mud guards.

- a. Using your existing factory fasteners, attach the mud guard at locations A and B.
- b. Use the mud guard as a template to mark and then drill a 1/8" hole at location D.
- c. Screw #10 Screw and Washer into newly-drilled locations D.